

**POSTED:** 10/09/2000

### Plume Maps

This note updates the guidance concerning what contamination "plume maps" need to be submitted in a Tier 1 or Tier 2 when chemical of concern concentrations are less than action levels. The changes are in bold print:

- A map must be submitted for any chemical of concern that exceeds action levels.
- A benzene map must be submitted regardless of concentration.
- A TEH map must be submitted, regardless of concentration, if TEH was included in the site sampling. **The exception to this is TEH-Waste Oil in soil. TEH-Waste Oil in soil maps are not required.**

The above applies even if an SCR has been previously approved for the site. Maps must be submitted if replacement soil borings and/or soil gas points have been installed.

Please contact Elaine Douskey at (515)281-8011 or [elaine.douskey@dnr.iowa.gov](mailto:elaine.douskey@dnr.iowa.gov) if you have any questions.

[www.iowadnr.gov](http://www.iowadnr.gov)